

Laser Centering Device

for ERESKO MF3/4



Application

The alignment of the workpiece to be inspected with the central beam of the X-ray tube and vice versa can be greatly simplified through

the usage of a mini laser instead of a centering rod. For this purpose the laser is swivelled in front of the X-ray tube window and activated

by the toggle switch. Prior to the exposure the laser must be turned off and swivelled out of the X-ray beam.

- The mini laser battery has a very long life due to the energy-saving pulsed operation.
- This laser complies with laser class II as per DIN EN 60825 (VDE 0837) / IEC 60825-1-2007 and FDA performance standards and is labeled accordingly.

WARNING: Do not stare into laser beam !



Technical Data

Laser type	Visual laser diode
Output power	<= 1 mW
Wave length	650 nm
Beam color	red
Battery	1x 3,0 V CR 123 or equivalent
Diameter	22 mm
Length	105 mm

Switch laser on/off

Press the button (1) to switch the laser on/off.

Changing the batteries

- To insert new batteries remove the screw cap.
- Remove the batteries, they should be placed in a recycling container.
Do not dispose batteries in domestic waste containers!
- Insert one 3,0 V CR 123 battery.
Observe correct polarity of the battery.
- Close the battery case with the screw cap.



www.gemeasurement.com/x-ray

GEIT-30226EN (10/15)

© 2015 General Electric Company. All Rights Reserved. Specifications are subject to change without notice. GE is a registered trademark of General Electric Company. Other company or product names mentioned in this document may be trademarks or registered trademarks of their respective companies, which are not affiliated with GE.

Contact: GE Sensing & Inspection Technologies GmbH, Bogenstrasse 41, 22926 Ahrensburg, Germany, T +49 (0)4102 807 0